PAPER MACHINE AUXILIARY EQUIPMENT

AUTO WIRE TENSIONER

Auto Wire Tensioner is used to keep the fabric tension at a constant level.

It moves the stretcher arms into one direction means to tension the fabric, moving it into opposite direction means to release the fabric. Stretcher arms are pivoted by a lever system connected to gliding shoes running on profiled beams within the housing. Keeping the fabric tension at a constant level means to :

- 1. Optimize paper quality and productivity.
- 2. Reach maximum fabric life.
- 3. Avoid overstretching and risk of damage at bearings or roll breaks.
- 4. Increase drying efficiency at the dryer cylinders.
- 5. Reduce sheet breaks.
- 6. Avoid slippage of drive rolls.



Salient Features:

- M.S. fabricated Lever Arms, Base Frames & support brackets for lever.
- Gab Brackets for tension roll of C.I. Gr. 25.
- Cross shafts made of M.S Pipe claded with S.S.304 sheet.
- Control Panel for adjusting the air pressure on both sides.
- Imported Rubber Bellows complete with bead plates.
- Suitable for shower and doctor assemblies.
- All the Hinge Pins will be of S.S.304.
- All M.S. Parts will be coated with two coats of epoxy paint.
- All fasteners will be of S.S.
- Easy to operate.

Global Paper Machinery & Engg. Co.



Global Paper Machinery & Engg. Co.

82,Ganga Sagar Scheme, 200 Feet Bypass, Sirsi Road, Jaipur-302021 Tel: +91-141-5179040,2470290, Fax: +91-141-5179040 Email: sales@globalpapermachine.com

www.globalpapermachine.com

© Copyright 2006 Global Paper Machinery & Engg. Co. Contact for the detail. Rev 00-0